

 **Vážený zákazníku,**
do rukou se Vám dostává: Termoska vyrobena z vysoko kvalitní nerezavějící oceli. Tlačítkový/šroubovací mechanismus otevření termosky vyroben z vysoko kvalitního plastu. Nerezová vložka čini termosku téměř nerozbitnou. Pojistkový mechanismus zabráňující nečekané otevření. Snadná údržba a čištění. 3 roky záruka.

Návod k použití:

- 1.) Výrobek z velmi kvalitní nerezové oceli. Vnitřní vložka termosky také z nerezové oceli pro uložení studených i teplých nápojů.
- 2.) Termosku vždy před každým použitím vymyjte teplou nebo studenou vodou dle nápoje, který bude do termosky nalit.
- 3.) Nádobu při použití plňte vždy max. ke spodnímu okraji vylevávací části termosky a to nejméně 1–1,5 cm pod okraj termosky. Do termosky nelijte nikdy vroucí nápoje.
- 4.) Teplota nápojů v termosce závisí na množství obsahu nápoje, častoti otevírání a teplotě v daném okolí. Pro dlouhé udržení teploty nápoje v termosce vždy rádně uzavírete a utáhněte uzávěr. Termosku ponechávejte ve svíslé poloze.
- 5.) Nespotřebovaný nápoj vždy vylijte, předejdete tím tvorbě usazenin uvnitř nádoby a případnému množení bakterií. Vždy budte opatrní při manipulaci s teplou vodou (nádobou).
- 6.) Před prvním použitím výrobek vždy omyle a utřete do sucha.
- 7.) Pro odstranění lehkých skvrn nechte nádobu odmočit a následně utřete dosucha měkkým hadrem. V případě skvrn ohřejte trochu bílého octu a potom umyjte běžným způsobem. Tyto skvrny však v žádném případě nesnižují vlastnosti produktu.
- 8.) Termosky se velmi dobře udržují a čistí, při ručním mytí používejte pouze měkké hadry a houbičky, které nepoškrábou daný povrch. Nepoužívejte agresivní chemické produkty.
- 9.) Pro zachování dlouhé životnosti výrobku, zacházejte s termoskou opatrně – vyhýbejte se silným nárazům a otřesům. Skladujte vždy otevřenou.
- 10.) **POZOR:** do nádoby nepatří syčené nápoje, kostky ledu nebo výrobky mléčné. Termoska není určena pro kojeneckou výživu.
- 11.) Určeno pro použití v domácnosti
- 12.) Záruka 3 roky se nevtahuje na : poškození pádem nebo úderem výrobku, technickou úpravou termosky.

Bezpečnostní upozornění:

Vlivem vysoké teploty může dojít k poškození nádoby nebo vika. Při použití ostrých kovových nástrojů může dojít k poškození (poškrábání) povrchu (např. nůž, vidlička). Při použití drsných a agresivních čisticích prostředků může dojít k poškození povrchu (např. žiravé prostředky na čištění trub). Při neopatrné manipulaci (např. s vikem) může dojít k poškození povrchu (otlučením). **Tyto „stop“ nemají sebemenší vliv na kvalitu přípravy jídla nebo nápojů ani celkovou životnost nádoby, pouze je narušen esteticky vzhled.** Vlivem nastavení vysoké teploty zdroje tepla, může dojít k poškození povrchu.

Ekologie:

Dle velikosti produktu, jsou na všech výrobcích vytiskeny znaky materiálů použitych na výrobu balení, komponentů a příslušenství, jakož i jejich recyklace. Správnou likvidaci tohoto produktu pomůžete zachovat cenné přírodní zdroje a napomáháte prevenci potenciálních negativních dopadů na životní prostředí a lidské zdraví, což by mohly být důsledky nesprávné likvidace odpadů. Další podrobnosti si vyžádejte od místního úřadu nebo nejbližšího sběrného místa. Při nesprávné likvidaci tohoto druhu odpadu mohou být v souladu s národními předpisy uděleny pokuty. **Igelitový sáček odkládejte mimo dosah dětí, nebezpečí udušení.**

Kupující byl seznámen s funkcí a se zacházením s výrobkem.

 **EN Dear customer,**

you are now holding: A vacuum flask made from high quality stainless steel. A button/screw mechanism for opening the vacuum flask made from high quality plastic. A stainless steel insert makes the vacuum flask practically indestructible. Locking mechanism prevents accidental opening. It is easy to maintain and clean. 3-year warranty.

Operating instructions:

- 1.) The product is from very high quality stainless steel. The internal insert of the vacuum flask is also from stainless steel designed for storing cold and warm beverages.
- 2.) Wash out the vacuum flask before every use with hot or cold water depending on the beverage that you will pour into the vacuum flask.
- 3.) Never fill the flask higher than the bottom edge of the pouring part of the vacuum flask, i.e. be at least 1 – 1.5 cm under the rim of the vacuum flask. Never pour boiling beverages into the vacuum flask.
- 4.) The temperature of the beverage in the vacuum flask depends on the beverage volume inside of it, frequency of opening and the ambient temperature. To maintain the temperature of the beverage in the vacuum flask for a long time, always properly close and tighten the cap. Keep the vacuum flask in a vertical position.
- 5.) Always pour out unconsumed beverages to prevent deposits from forming inside the flask and potential bacterial growth. Always be careful when handling hot water (the flask).
- 6.) Before first use, always wash the product and wipe dry.
- 7.) To remove light stains, allow the flask to soak and then wipe it dry with a soft wiping cloth. If it does become stained, heat up some white vinegar and then wash as usual. These stains have no effect on the properties of the product.
- 8.) Vacuum flasks are very easy to maintain and clean; when cleaning by hand use only soft wipes and sponges that will not scratch the surface. Do not use aggressive chemical products.
- 9.) To achieve a long lifetime of the product, handle the vacuum flask with care – avoid strong impacts and shocks. Always store opened.
- 10.) **ATTENTION:** carbonated and sparkling beverages, ice cubes or dairy products do not belong in the flask. The vacuum flask is not to be used for baby food.
- 11.) Designed for domestic use
- 12.) The 3-year warranty does not cover: damage caused by the product falling or being impacted, technical modifications of the vacuum flask.

Safety notice:

High temperatures may damage the flask or the cap. The use of sharp metal utensils (e.g. knives, forks) may damage (scratch) the surface. The use of coarse or aggressive cleaning agents can damage the surface (e.g. caustic pipe cleaning agents). Negligent handling (e.g. of the cap) may lead to surface damage (chipping). **These „footprints“ do not have the slightest effect on the quality of the prepared food or beverages nor on the lifetime of the flask, they only affect its aesthetic appearance.** Through the effect of high temperature of the heat source, the surface may be damaged.

Ecology:

Depending on the size of the product, all products have marks printed on them denoting the material used for the production of the packaging, component and accessories, as well as their recycling. Correct disposal of this product helps save valuable natural resources and prevents damage to the environment caused by improper waste disposal. Ask your local authorities or collection facility for more details. In accordance with national regulations penalties may be imposed for the incorrect disposal of this type of waste. **Keep plastic bags out of the reach of children, danger of suffocation.**

The purchaser was informed about the function and handling of the product.